RiTTO

TwinBus IP

Video indoor station

Installation Guide

In this document you will find all information for safe installation.

RGE2087750 | RGE2087770

2022/04






Table of contents

For your safety
About this document
Trademarks4
Scope of supply
Introduction to the TwinBus IP Video indoor station5
Device overview
The right place to install
Installation
Set the indoor station orientation
Installation on a size 60 installation box
Mounting the indoor station on the base plate
Pin assignment
Wiring diagrams / Block diagrams
Single-family house 13 Wiring diagram 13 Block diagram 15
2-family house
Block diagram
Technical data19
WEEE
FII declaration of conformity 21

Safety instructions

Read these instructions carefully and familiarize yourself with the device before installing or operating it. The following specific instructions may appear in this manual or on the device to warn against potential dangers or to draw attention to information that explains or simplifies a procedure



The addition of this symbol to the "danger" or "warning" precautions informs about an electrical danger which may cause serious injury if the instructions are not followed.



This is a safety warning symbol. It informs you about possible risks of injury. Follow all safety instructions with this symbol to avoid potential injury or fatal injury.

A DANGER

DANGER refers to an immediately dangerous situation which, if not observed, will lead to serious injuries or death.

WARNING

WARNING points to a dangerous situation which may lead to serious injury or death if not avoided.

A CAUTION

CAUTION indicates a dangerous situation which may lead to minor or moderate injuries if not avoided.

NOTICE

A **NOTICE** indicates that there is no risk of injury.

Additional comments



More information can be found here to make your work easier.

For your safety

en

A A DANGER

Hazard of electric shock, or arc flash

Safe electrical installation must be carried out only by skilled professionals. Skilled professionals must prove profound knowledge in the following areas:

- Connecting to installation networks
- Connecting several electrical devices
- Laving electric cables
- Safety standards, local wiring rules and regulations

Failure to follow these instructions will result in death or serious injury.

About this document

In this document you will find all information for safe installation.



For more detailed product information, such as start-up or settings, follow the QR code.



https://www.merten.de/profibereich/service/downloads.html

Trademarks

Wi-Fi[®] is a registered trademark of the Wi-Fi Alliance.

Scope of supply

Video indoor station, horizontal support plate, vertical support plate, plug-in terminal, fastening material, drilling template, installation guide

Introduction to the TwinBus IP Video indoor station

The TwinBus IP Video indoor station (hereinafter referred to as the indoor station) is a 7 inch touch screen video intercom unit for wall mounting. It serves as a video/audio communication unit in the TwinBus IP System.

The indoor station can be monitored horizontally or vertically. To do this, use the appropriate supporting plate supplied with the product.


The indoor station has the following functions:

- Video and audio communication to the TwinBus IP Door station.
- Internal calls between different indoor stations (audio only)
- Triggering of switching commands such as door opening (light control with optional accessory).
- Video preview of the camera at the door station.
- Individual settings, such as the choice of ringtone or door opening time

The indoor station complies with the requirements for use in residential locations

Device overview


en Front



- (A) Display of mute / missed calls
- **B** Microphone

- © Restart button
- 7" touch panel

Rear




A Base plate

© Terminal strip with plug-in terminals

(B) Mounting plates

The right place to install



The indoor station must be mounted in a way that the microphone is not covered.

When choosing the installation location, the maximum cable length must be observed. The following table shows the lengths from the indoor station to the respective assemblies in the system.

	Group 0.8 mm Cable	Group 0.6 mm Cable	Group 0.5 mm Cable
REG bus filter	120 m	80 m	50 m
Door station (to the furthest indoor station)	200 m	140 m	100 m
External REG power supply (required for additional indoor stations)	50 m	50 m	50 m
Optional apartment button	5 m	5 m	5 m
Optional push-button to unlock the door	5 m	5 m	5 m

Group 0.8 mm cable: YR 2x0.8 mm, J-Y(ST)Y 2x2x0.8 mm, A-2Y(L)2Y 2x2x0.8 mm, CAT5e / CAT6 0.8 mm

Group 0.6 mm cable: A-2Y(L)2Y 2x2x0.6 mm, J-Y(ST)Y 2x2x0.6 mm, CAT5e / CAT6 0.8 mm


Group 0.5 mm cable: CAT5e / CAT6 0.5 mm

When using a shielded cable, the shield must not be connected.

Installation

Set the indoor station orientation

The mounting plates of the hooks are pre-mounted for horizontal orientation of the indoor station. If you want to mount the indoor station vertically, adjust the orientation of the mounting plates.




- 1) Remove all 4 mounting plates.
- 2 Rotate and screw the mounting plates back on.

Attaching the support plate to the wall

en When attaching the support plate to the wall, the position and number of screws depend on the orientation of the indoor station.

The support plate can either be mounted on a size 60 installation box or directly on the wall.

Installation on a size 60 installation box




- (1) Screw the appropriate supporting plate on a size 60 installation box using 2 screws according to the desired orientation.
- (2) Screw the supporting plate to the wall with the remaining screws.


Installation on the wall

(1) Screw the appropriate supporting plate to the wall with 4 screws (horizontal alignment) or 3 screws (vertical alignment) according to the desired orientation.

Mounting the indoor station on the base plate



1 Perform connection according to the wiring diagram.




② Insert the indoor station on the base plate.

en

NOTICE

You can compensate for unevenness in the wall by slightly adjusting the four brackets on the base plate.

Pin assignment



- (A), (C) B Bus -
- (B), (D) A Bus +
- (E), (F) DU Door opener


- G, H AP Apartment button
- (I) PS+ Power Supply (optional)
- (J) PS- Power Supply (optional)

Wiring diagrams / Block diagrams

The system configuration can be executed in star or bus structure.

Single-family house

Wiring diagram



(1) Terminal strip

en

- (2) Door opener (AC/DC) via potential-free contact
- (3) Door opener, DC 6 V ... 12 V, max. 800 mA Connecting the door opener to the outdoor unit can be expedient if an existing cable installation can be used

Notice: If the door station is broken into by force, the door opener can be operated by trespassers. Therfore this installation method is strongly disvouraaed.

- (4) A WARNING Danger to life due to electric shock
 - Use only a SELV power supply.

Failure to comply with this instruction may result in death or serious injury.

- (4a) Connection of an additional power supply (DC 24 V ... 28 V, 2,5 A) if the cable length to the bus filter exceeds 1 m.
- (4b) Connection of an additional power supply (DC 24 V ... 28 V, 2.5 A) if the cable length from the door station to the door opener exceeds 80 m.
- (5) For example, an external card reader
- NO Normally open contacts of the indoor station: Connection of a push-button to unlock the door (DU) and to connect an apartment button ED (AP).
- ΤÖ Door opener

Power supply of the system:

One REG power supply RGE2057100 can supply the following components:

- REG bus filter. 1 indoor station and 1 door station with door opener at the A Bus +/B Bus - connection or
- 3 indoor stations at the PS+/PS- connection


Minimum system configuration:

1x indoor station, 1x door station, 1x REG bus filter, 1x REG power supply

Maximum system configuration:

Minimum system configuration plus max. 3 further indoor stations powered by 1 additional REG power supply.


Block diagram



- The connection of the indoor station with a router enables the use of the TwinBus IP app and the time synchronization with an NTP server.
- ** The optional connection to other indoor stations is only used for NTP time synchronization on the Internet.

2-family house

Wiring diagram en



- (1) Terminal strip
- (2) Door opener (AC/DC) via potential-free contact
- (3) Door opener, DC 6 V ... 12 V, max. 800 mA Connecting the door opener to the outdoor unit can be expedient if an existing cable installation can be used.

Notice: If the door station is broken into by force, the door opener can be operated by trespassers. Therfore this installation method is strongly disvouraaed.

- (4) A WARNING Danger to life due to electric shock
 - Use only a SELV power supply.

Failure to comply with this instruction may result in death or serious injury.

- (4a) Connection of an additional power supply (DC 24 V ... 28 V, 2,5 A) if the cable length to the bus filter exceeds 1 m.
- (4b) Connection of an additional power supply (DC 24 V ... 28 V, 2,5 A) if the cable length from the door station to the door opener exceeds 80 m.
- (5) For example, an external card reader
- NO Normally open contacts of the indoor station: Connection of a push-button to unlock the door (DU) and to connect an apartment button ED (AP).
- ΤÖ Door opener

Power supply of the system:


One REG power supply RGE2057100 can supply the following components:

- REG bus filter. 1 indoor station and 1 door station with door opener at the A Bus +/B Bus - connection or
- 3 indoor stations at the PS+/PS- connection

Maximum system configuration:

8x indoor stations (for each household 4 indoor stations), 1x door station, 1x REG bus filter. 4x REG power supply

Block diagram



For information on connecting the indoor station with a router see Block diagram --> 15 in chapter Single-family house.

Technical data

Indoor station performance data

Input voltage (Bus) SFLV DC 24 V

SELV DC 24 V Input voltage on external power supply (required for additional indoor stations)

Current consumption < 0.4 A

Connection terminal

1x 0.5 mm ... 0.8 mm solid Clamping range (conductor diameter)

> 1x AWG 24 AWG 20 solid Copper-clad aluminum conduc-

tors must not be used

0.2 Nm Nominal torque

TouchPanel

Screen diagonal 17.47 cm (7")

Resolution 1024x600

Horizontal orientation

Vertical top / bottom viewing angle 30° / 70°

Horizontal right / left viewing angle 70° / 70°

Vertical orientation

Vertical top / bottom viewing angle 70° / 70°

Horizontal right / left viewing angle 30° / 70°

Luminance/contrast ratio 500

Typical response time (at 25 °C) 25 ms

Screen type Capacitive, multi-touch

Wi-Fi®

en

Frequency band

2.4 GHz band 2400 MHz ... 2483,5 MHz

5 GHz band 5150 MHz ... 5250 MHz

5 GHz (SRD) band 5745 MHz ... 5825 MHz

Transmission power (max.)

2.4 GHz band 71 mW

5 GHz band 85.5 mW

5 GHz (SRD) band 24.5 mW

Range (without obstruction) 20 m

Environmental conditions

-10 °C ... 55 °C Ambient temperature

96% Humidity (max)

Dimensions and weight

Installation heigh < 2 m

Dimensions (W x H x D) 197 x 133 x 25.2 mm

Weight approx. 512 g

Protection class IP30

WEEE



Dispose of the device separately from household waste at an official collection point. Professional recycling protects people and the environment against potential negative effects.

EU declaration of conformity

Schneider Electric Industries hereby declares that this product complies with the essential requirements and other relevant provisions of the RADIO equipment Directive 2014/53/EU. The declaration of conformity can be downloaded here: schneider-electric com/docs

en

Schneider Electric GmbH c/o Ritto

Gothaer Strasse 29, 40880 Ratingen, Germany

Customer Service:

Telephone: +49 211 7374 8008

www.ritto.de

© 2022 Schneider Electric, all rights reserved

NNZ42645-01 2022/04